


FIG.1**MOBILE STATION 10**

0000000000 - 0000 0000 00


FIG.2**BASE STATION SYSTEM 20**

FIG.3

SHO CONTROL UNIT 221




FIG.4**SHO CORRECTION VALUE TABLE****SHO DESTINATION CANDIDATE CELL 2222**

SHO SOURCE
CELL 2221

\backslash	CELL 1	CELL 2	CELL n
CELL 1		Δ_{12}	Δ_{1n}
CELL 2	Δ_{21}		Δ_{2n}
...
CELL n	Δ_{n1}	Δ_{n2}	

2223




FIG.5A**FIG.5B****FIG.5C**

FIG.6

SHO CONTROL UNIT 221





FIG.7

SHO CONTROL UNIT 221



00000000-0000-0000-0000-000000000000

FIG. 8

RESULT TABLE

SHO DESTINATION CANDIDATE CELL 2222

8/15

FIG.9

BASE STATION SYSTEM 20




FIG.10

PERCH CHANNEL POWER CONTROL UNIT 224

00000000000000000000000000000000





FIG.11**MOBILE STATION 10'**

FIG.12

SHO CONTROL UNIT 18




FIG.13

SHO CONTROL UNIT 221






FIG.14**FIG.15**

FIG.16

